



NOTE:

1. SEE ADDITIONAL TRIM TEMPLATE WHEN REQUIRED.
2. MOUNTING HOLES TO BE DRILLED WHEN INSTALLING HARDWARE.

REV. No. 2	REVISION: CHANGE DEMENSION	DATE: 8-1-00
------------	----------------------------	--------------



9100 & F9100
 CONCEALED VERTICAL ROD EXIT DEVICE
 WOOD DOOR ROUTING INSTRUCTIONS

TEMPLATE NUMBER
 T-9118WD

