INS NO. **08280782** PAGE 2 of 3 Rev. 10/10 Always consult DORMA's web site for latest template at www.dorma-usa.com or call 1-800-523-8483. NOTES: 1) DO NOT SCALE THIS DRAWING 2) DIMENSIONS ARE IN INCHES / [MM] 3) LEFT HAND DOOR IS SHOWN 4) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS. UNLESS ANALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS. 5) MAX. OPENING 180 DEG. 6) SEE CATALOG FOR REVEAL INFORMATION 7) OPTIONAL DPK FASTENERS (DPK89) FOR STEEL DOOR & FRAME ONLY. ₽ OF FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP HINGE OR PIVOT FOR No.14 WOOD SCREWS, USE 5/32" DRILL 10-1/4" FOR DPK FASTENERS, USE 1/8" DRILL [127] 260 FOUR (4) HOLES IN FRAME ARE FOR CLOSER 5/8" [16] তি ₩. [19] [48] FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP 1-3/4" FOR No.14 WOOD SCREWS, USE 5/32" DRILL [44] 9-1/2" FOR DPK FASTENERS, USE 1/8" DRILL [241] FOR SEX NUTS, USE 3/8" DRILL TWO (2) HOLES IN DOOR ARE FOR ARM SHOE REVEAL SEE NOTE -#6

