
NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. DIMENSIONS ARE IN INCHES/(MM).
- 3. LEFT HAND DOOR SHOWN.
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAX. OPENING IS 180°
- 6. SEE CATALOG FOR REVEAL INFORMATION.
- 7. OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.




DOOR CLOSER MODELS: 8616 AFJ OR ARJ (NHO) TOP JAMB INSTALLATION (PUSH SIDE MOUNT)



NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. DIMENSIONS ARE IN INCHES/(MM).
- 3. LEFT HAND DOOR SHOWN.
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAX. OPENING IS 180°
- 6. SEE CATALOG FOR REVEAL INFORMATION.
- 7. OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.




DOOR CLOSER MODELS: 8616 AFJ OR ARJ (NHO) TOP JAMB INSTALLATION (PUSH SIDE MOUNT) WITH PLATES BP86, BP86FC



NOTES:

- 1. DO NOT SCALE DRAWING. 2. DIMENSIONS ARE IN INCHES/(MM).
- 3. LEFT HAND DOOR SHOWN.
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAX. OPENING IS 180°.
- 6. SEE CATALOG FOR REVEAL INFORMATION.
- 7. OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.



DOOR CLOSER MODELS: 8616 AFJ OR ARJ (NHO) TOP JAMB INSTALLATION (PUSH SIDE MOUNT) WITH PLATE DP86

