## dormakaba 7300 AR right hand (2)**REGULAR TEMPLATE** 7/8" [22] 9-1/2" 1-3/4" [241] [44] ALIGN LINE WITH BOTTOM OF FRAME FACE. ALIGN WITH CENTER LINE OF HINGE. VERIFY EXACTLY 1" [25.4]. **}**+++++++**}**+++++++**}** 0 1 MEASURE SCALE AFTER PRINTING. TEMPLATE TO SCALE 1:1, FULL SIZE (4) 9-1/16" [230] 5" [127] × 7300 AR left hand (2) (+)METAL - 7/32" & 1/4-20 TAP, FOR WOOD 5/32", **REGULAR TEMPLATE** (FOR SEX NUTS USE 3/8") 7/8" OPTIONAL SELF TAPPING SCREWS 7/32" [22] 1-3/4" 9-1/2" [44] [241] ALIGN LINE WITH BOTTOM OF FRAME FACE. 1-1/4" [32] 3/4" [19]

9-1/16" [230]

(4)



METAL - 7/32" & 1/4-20 TAP, FOR WOOD 5/32", (FOR SEX NUTS USE 3/8") OPTIONAL SELF TAPPING SCREWS 7/32"



