



- NOTE:
1. SEE APPROPRIATE DEVICE TEMPLATE FOR INSIDE DOOR PREP.
 2. SEE ADDITIONAL TRIM TEMPLATE WHEN REQUIRED.
 3. MOUNTING HOLES TO BE DRILLED WHEN INSTALLING HARDWARE.

REV. No. 2 REVISION: DIM. WORDING DATE: 2-10-16



9600
 CONCEALED VERTICAL ROD TYPE
 EXIT DEVICE
 (WOOD DOOR PREP)

TEMPLATE NUMBER
 T-9600WD
 ②