

8900 High Security Cover Attachment Installation Instructions

Fig. 1

1.3.1 Attach cover with four torx screws using two spacers (provided), between bottom of closer body and bottom inside of cover.

1.3.2 Spacers are required to prevent pinion from rubbing cover.

NOTE: Top jamb mounted covers are handed (left or right hand).

