INS NO. 08280074


Ç|OF HINGE OR PIVOT PAGE 1 OF 1

Rev. **06/10** 


Always consult DORMA's web site for latest template at www.dorma-usa.com or call 1-800-523-8483.

## NOTES:

- 1) DO NOT SCALE THIS DRAWING
- 2) DIMENSIONS ARE IN INCHES / [MM]
- 3) LEFT HAND DOOR IS SHOWN
- 4) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5) PLEASE SEE CATALOG FOR REVEAL INFORMATION.
- 6) OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.



ANGLE OF CUSHION	DIMENSION "A" (CLOSER)	DIMENSION "B" (ARM SHOE)
83° - 85°	7"	12-7/8"
	[178]	[327]
88° - 90°	6-1/4"	12-3/8"
	[159]	[314]
93° - 95°	6"	12"
	[152]	[305]
98° - 100°	5-3/4"	11-1/2"
	[146]	[292]
103° - 105°	5-1/2"	11-1/4"
	[140	[286]
108° - 110°	5-1/4"	11"
	[133]	[279]



DOOR CLOSER MODELS: 8616 ISJ TOP JAMB INSTALLATION (PUSH SIDE MOUNT) INTEGRA CUSHION ARM





DORMA Architectural Hardware Reamstown, PA 17567

INS NO. 08280075 PAGE 1 OF 1 Rev. 06/10 Always consult DORMA's web site for latest template at www.dorma-usa.com or call 1-800-523-8483.

## NOTES:

- 1) DO NOT SCALE THIS DRAWING
- 2) DIMENSIONS ARE IN INCHES / [MM]
- 3) LEFT HAND DOOR IS SHOWN
- 4) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5) PLEASE SEE CATALOG FOR REVEAL INFORMATION.
- 6) OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.





DOOR CLOSER MODELS: 8616 ISJ TOP JAMB INSTALLATION (PUSH SIDE MOUNT) WITH BACK PLATE BP86 & BP86FC INTEGRA CUSHION ARM



DORMA Architectural Hardware Reamstown, PA 17567


INS NO. 08280076 PAGE 1 OF 1 Rev. 06/10 Always consult DORMA's web site for latest template at www.dorma-usa.com or call 1-800-523-8483.


FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP

FOR No.14 WOOD SCREWS, USE 5/32" DRILL

## NOTES:

- 1) DO NOT SCALE THIS DRAWING
- 2) DIMENSIONS ARE IN INCHES / [MM]
- 3) LEFT HAND DOOR IS SHOWN
- 4) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5) PLEASE SEE CATALOG FOR REVEAL INFORMATION.
- 6) OPTIONAL DPK FASTENERS (DPK86) FOR STEEL DOOR & FRAME ONLY.





DOOR CLOSER MODELS: 8616 ISJ TOP JAMB INSTALLATION (PUSH SIDE MOUNT) WITH DROP PLATE DP86 INTEGRA CUSHION ARM

Ç|OF HINGE OR PIVOT



DORMA Architectural Hardware Reamstown, PA 17567