dormakaba 7300 A08 right hand METAL - 7/32" & 1/4-20 TAP, FOR WOOD 5/32", REGULAR TEMPLATE (FOR SEX NUTS USE 3/8") 7/8" 9-1/2" OPTIONAL SELF TAPPING SCREWS 7/32" 1-3/4" [22] [241] [44] ALIGN LINE WITH BOTTOM OF FRAME FACE. ALIGN WITH CENTER LINE OF HINGE. 1-1/4" [32] **VERIFY EXACTLY** 1" [25.4]. 3/4" [19] **MEASURE SCALE** AFTER PRINTING. TEMPLATE TO SCALE 1:1, FULL SIZE (4) 9-1/16" [127] [230] 7300 A08 left hand (2) METAL - 7/32" & 1/4-20 TAP, FOR WOOD 5/32", **REGULAR TEMPLATE** (FOR SEX NUTS USE 3/8") 7/8" OPTIONAL SELF TAPPING SCREWS 7/32" 1-3/4" 9-1/2" [22] [44] [241] - ALIGN LINE WITH BOTTOM OF FRAME FACE. ALIGN WITH CENTER LINE OF HINGE. 1-1/4" [32] **VERIFY EXACTLY** 1" [25.4]. |----- 3/4" [19] **MEASURE SCALE** AFTER PRINTING. TEMPLATE TO SCALE 1:1, FULL SIZE 9-1/16" [230] [127]