



- NOTES:
1. DIMENSIONS ARE IN INCHES/[MM].
  2. DO NOT SCALE DRAWING.
  3. FOR #12 FHWS, USE 9/64" (.140") DRILL.
  4. FOR #12-24 FHMS, USE #16 (.177") DRILL & TAP.

DOOR CUT-OUTS AS INDICATED UNDER DOOR DETAIL.  
FRAME FOR STRIKE SHOWN UNDER LOCK DETAIL.

**WOOD DOORS - A&B Rose Trim, M Escutcheon Trim**  
M9957, M9958, M9966, M9967, M9968, M9974



DORMA Architectural Hardware  
Reamstown, PA 17567

