BTS75V/I, 80/I x butt hinges

Package I Push side mortised track - 90° opening

Installation instructions

08083291 - 02-2021



dormakaba 🚧

Table of contents

1 1.1 1.2 1.3 1.4	Installation Attach spindle and install closer Install slide block to arm Install slide arm (7451) into track Install arm to closer	3 3 3 3 4
2	Templates	4
2.1	Closer template	4
3 3.1	Adjustments Adjust bottom door clearances (if necessary)	5 5
3.2 3.3	Adjust closing speeds Adjust spring tension	5
		5
	Adjust spring tension	-

2


Installation 1

Attach spindle and install closer 1.1

Fig.1


- 1.1.1 Slide washer over tapered square end of spindle until fully seated in groove.
- 1.1.2 Fasten spindle with spindle screw provided.
- 1.1.3 Tighten securely with 5mm hex key.

CRITICAL: WASHER MUST BE INSTALLED



- 1.1.4 Center closer in cement case.
- 1.1.5 Tighten fastening screws.


1.2 Install slide block to arm Fig.2



Spindle screw


Spindle

NOTE: Top of cement case must be flush with finished floor. NOTE: Cement case must be level and installed parallel to frame. NOTE: Spindle center line must be accurately located. NOTE: Grout cement case in place.




Install slide arm (7451) into track 1.3 Fig.3






1.4 Install arm to closer Fig.4



2 **Templates** 2.1 Closer template

Fig.5




4

3 Adjustments

3.1 Adjust bottom door clearances (if necessary)

Fig.6




- 3.1.1 Closer can be raised approximately 5/32" with the cement case.
- 3.1.2 Loosen fastening screws "A".
- 3.1.3 Turn height adjustment screws "B" CW until desired height is obtained.

NOTE: Closer must remain level!


- 3.1.4 Re-tighten fastening screws "A".
- 3.1.5 If more clearance is necessary, change spindle to appropriate size.

3.2 Adjust closing speeds

Fig.7



3.3 Adjust spring tension (BTS75V ONLY; if necessary) Fig.8




3.4 Sealing compound (optional)

Fig.9

Sealing compound is recommended for exterior doors or areas with excessive moisture. Make all final adjustments before adding compound. Refer to instructions packed with compound for full details.

4 Covers

4.1 Install cover



6

dormakaba DORMA USA, Inc. T: 800-523-8483