

T900

Lever for wood or metal doors

Drilling Template [FULL SIZE]

**IMPORTANT: CHECK
DOOR THICKNESS
BEFORE DRILLING.**

DRILL 1" [25.4] DIA.
HOLE ON DOOR EDGE
CENTER LINE.

