



LA GARD 700 Series

Simple Set-Up: 701 with 1 Manager/ 1 Standard User/6 Digit Combination













Navigation Tips

- Any key press wakes the system. The commands below are shown with the  as the key press for waking the system. When not needed, the lock will respond with a short red flash and low beep signaling that the lock is ignoring RETURN and waiting for your # command.
- # key during a command sequence will cancel the sequence
- Start a new open command string by entering id and combination
-  Return Key generally submits the prior keystrokes

Initial Set Up Commands (for 1 Manager/1 Standard User)

The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed the lock will respond with a short red flash and low beep signaling that the lock is ignoring that key and waiting for your # command.

Step	Action	Command String	Result
Step 1	Install with Preconfigured User: #50 #22	 #50 #22 00 12345678 	Keypad: 3 High Beeps with 3 Green Flashes Lock: Installed with Manager User 01 Enabled, Combination = 123456, Privileges: Users must change the combination for first use
Step 2	Add Standard User with Open Only: #50	Standard User  #50 00 12345678 02 123456 2 1  Open Only Privilege	Keypad: 3 High Beeps with 3 Green Flashes Lock: New User with Privileges as identified, Users must change the combination for first use
Step 3 Change Combinations	Change Master Combination: #52	 #52 00 (ID) 123456 (Combo) 00 (ID) _____ (New 8 Digit Combo) 00 (ID) _____ (New Combo) 	Keypad: 3 High Beeps with 3 Green Flashes Lock: Combination Changed
	Change Manager Combination: #52	 #52 01 (ID) 123456 (Combo) 01 (ID) _____ (New 6 Digit Combo) 01 (ID) _____ (New Combo) 	Keypad: 3 High Beeps with 3 Green Flashes Lock: Combination Changed
	Change Standard User Combination: #52	 #52 02 (ID) 123456 (Combo) 02 (ID) _____ (New 6 Digit Combo) 02 (ID) _____ (New Combo) 	Keypad: 3 High Beeps with 3 Green Flashes Lock: Combination Changed

Other System Function Settings

The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed the lock will respond with a short red flash and low beep signaling that the lock is ignoring that key and waiting for your # command.

Any key press wakes the system. The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed, the lock will respond with a short red flash and low beep signaling that the lock is ignoring RETURN and waiting for your # command.

Action	Command String	Requirement	Result
Set/Change Combination Length: #11	↵ #11 00 (ID) _____ (Combo) 6 ↵ for 6 digit	Master Only Note: Impact to existing user combinations	Keypad: 3 High Beeps with 3 Green Flashes Lock: Combination Length Changed NOYR: Changing the Combination Length will impact existing user combinations. Reset user combinations. Users must change the combination for first use
	↵ #11 00 (ID) _____ (Combo) 7 ↵ for 7 digit		
	↵ #11 00 (ID) _____ (Combo) 8 ↵ for 8 digit		
	↵ #11 00 (ID) _____ (Combo) 9 ↵ for 9 digit		
Set Buzzer to On/Off: #41	↵ #41 __ (ID) _____ (Combo) 0 ↵ for Buzzer Off	Master or Manager	Keypad: 3 High Beeps with 3 Green Flashes Lock: Buzzer is On/Off
	↵ #41 __ (ID) _____ (Combo) 1 ↵ for Buzzer On		
Enable FW Update Port: #99	↵ #99 __ (ID) _____ (Combo) ↵	Master or Manager	Keypad: 3 High Beeps with 3 Green Flashes, then will illuminate Red Lock: Can be configured by software
Open PC Link: #30	↵ #30 __ (ID) _____ (Combo) ↵	Master, Manager or User with Privilege	Keypad: 3 High Beeps with 3 Green Flashes, then will illuminate Red, Green LED blinks during data transfer Lock: Can be configured by software Note: 701 models only support PC LINK Compare. No programming or audit features exist.

Operation Commands

The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed the lock will respond with a short red flash and low beep signaling that the lock is ignoring that key and waiting for your # command.

Action	Command String	Requirement	Result
Change Combination: #52	↵ #52 00 (ID) 12345678 (Combo) 00 (ID) _____ (New Combo) 00 (ID) _____ (New Combo) ↵	Master, Manager or Standard User, Combination length 6-9 as required (Master requires 8)	Keypad: 3 High Beeps with 3 Green Flashes Lock: Combination Changed
Open Lock (Single User)	↵ __ (ID) _____ (Combo)	Manager or Standard User with Privilege	Keypad: 3 High Beeps with 3 Green Flashes Lock: Opens

User Administration Commands

The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed the lock will respond with a short red flash and low beep signaling that the lock is ignoring that key and waiting for your # command.

Action	Command String	Requirement	Result
Add User: #50	Standard User ⬅️ #50 __ (ID) _____ (Combo) __ (ID) _____ (Combo) 21 (Privilege) ⬅️ Open Only Manager User ⬅️ #50 __ (ID) _____ (Combo) __ (ID) _____ (Combo) 41 (Privilege) ⬅️ Open Only	Master or Manager Manager must be created by Master Combination Length must meet requirement	Keypad: 3 High Beeps with 3 Green Flashes Lock: New User with Privileges as identified
User Enable/Disable: #54	⬅️ #54 __ (ID) _____ (Combo) __ (User to Change) 0 ⬅️ Disable User ⬅️ #54 __ (ID) _____ (Combo) __ (User to Change) 1 ⬅️ Enable User	Master or Manager Manager must be managed by Master	Keypad: 3 High Beeps with 3 Green Flashes Lock: User enabled/disabled
Edit User Privileges: #55	⬅️ #55 __ (ID) _____ (Combo) __ (User to Change) 1 ⬅️ Open Only	Master or Manager Manager privileges must be edited by Master	Keypad: 3 High Beeps with 3 Green Flashes Lock: User Privilege changed as identified
Delete User: #56	⬅️ #56 __ (ID) _____ (Combo) __ (User to Delete)	Master or Manager Manager must be deleted by Master	Keypad: 3 High Beeps with 3 Green Flashes Lock: User Deleted
Reset User Combination: #57	⬅️ #57 __ (ID) _____ (Combo) __ (ID to Reset) _____ (New Combo) __ (ID to Reset) _____ (New Combo) ⬅️	Master or Manager Manager must be reset by Master Combination Length must meet requirement	Keypad: 3 High Beeps with 3 Green Flashes Lock: User with New Initial Combination, User will have new Initial Combination, User must change combination for first use.

Uninstall/Reinstall/Reset Keypad and Lock

The commands below are shown with the RETURN SYMBOL as the key press for waking the system. When not needed the lock will respond with a short red flash and low beep signaling that the lock is ignoring that key and waiting for your # command.

Action	Command String	Requirement	Result
Reinstall Keypad: #32	⬅️ #32 __ (ID) _____ (Combo) ⬅️	Privilege Required Open Privelege Required	Keypad: Alternating Red and Green Flashes indicate the same Keypad Model is not paired, Success indicated with 3 High Beeps with 3 Green Flashes Lock: Lock is Installed to Keypad
Uninstall Lock: #23	⬅️ #23 00 (ID) _____ (Combo) ⬅️	Master Only	Keypad: 3 High Beeps with 3 Green Flashes Lock: Is no longer installed to Keypad
Reset Lock: #25	⬅️ #25 00 (ID) _____ (Combo) ⬅️	Master Only	Keypad: 3 High Beeps with 3 Green Flashes Lock: Master Combination is reset to 12345678, All users deleted, All Factory Defaults restored, Lock will be uninstalled from Keypad