

90 09M Touchless switch – Remote control module

Installation and Instruction sheet

The remote module allows wireless activation of the 90 09M touchless switch.

1. Remove power to the switch prior to installing the PCB module. (Fig. 1)

Fig. 1



2. Align the pins on the module with the header on the switch and insert as illustrated below. (Fig. 2) Ensure the pins are aligned and fully engaged.

Fig. 2



3. Reapply power to the switch
4. Once installed the remote control needs to be paired to the receiving module for proper operation.

5. Locate the button and LED on the back of the module as illustrated below. (Fig. 3)

Fig. 3



6. Press and hold the button on the module until the red LED comes on, then release.
7. While the LED is illuminated, press the button on the remote control (Fig. 4), the LED will blink indicating the code is being stored.

Fig. 4



8. The red LED will go out to indicate the successful programming. Up to 5 remotes can be paired with the one receiver by following the above procedure. **Note:** If one remote needs to be reprogrammed or deleted, all remote's will be erased and will need to be reprogrammed individually.
9. To delete all units, press and hold the button on the back of the board until the red LED comes on. Continue to hold the button until the LED goes out.
10. Repeat steps 6-8 to reprogram.