e-data QUICK SETUP: TIME1500

Step 1 MOUNT



Step 2 POWER ON

A Connect Ethernet cable from corresponding port on bottom of terminal to Local Area Network (wall jack, network hub or router)

B Connect terminal to power supply

C Await IP address displayed on screen (example: 192.168.1.8)

Step 3 NETWORK

A Default IP address

At startup, the terminal automatically pulls an IP address (via DHCP); you must record the IP address displayed on screen for later access

B Setting a fixed IP address (optional)

Refer to Time1500 manual for step-by-step details



Step 4 LOG IN AND CONFIGURE

A Connecting to Time1500

Open the browser of the network-connected PC

Enter the IP address into the browser address bar

The Login screen is displayed



B Log in to the system

Enter the name “Administrator”

Enter the password “changeconfig”

Click Logon

C Modify system for your specific needs (refer to manual)



TERMINAL KEYPAD

Button	Function
Green	Clock in
Red	Clock out
F1	Start break
F2	End break
?	Self service
C	Clear
√	OK
Arrow	Up/down
Flag	Clock menu