


## **Installation Instructions**

3/4" Offset Lead Lined Top Pivot For use with 75140, 75142, 75143

## 1.1 Install pivot


Fig. 1



- 1.1.1 Prepare door and frame according to template.
- 1.1.2 Remove door portion cover cap.
- 1.1.3 Remove set screw.
- 1.1.4 Remove pivot pin.
- 1.1.5 Fasten pivot to door and frame.
- 1.1.6 Install door.

- 1.1.7 Align door and frame portion of top pivot.
- 1.1.8 Install pivot pin making sure undercut area of pin aligns with set screw.
- 1.1.9 Tighten set screw securely.
- 1.1.10 Install door portion cover cap.

NOTE: Depending on type of pivot and hand of door, set screw may be in door portion or frame portion of pivot. However, pivot will always be removeable through door portion.



TMP NO. LM-36

PAGE 1 OF

REV. 02/21

ALWAYS CONSULT DORMAKABA'S WEBSITE FOR LATEST

3/4" OFFSET FULL MORTISE TOP PIVOT ALL SERIES: [75140, [75140 5/8, 75142 5/8, 75143 5/8 (DOOR INSET 1/8" FROM FRAME) HANDED] 75142, 75143 (DOOR FLUSH WITH FRAME) NON-HANDED],

FOR LEAD LINED OR EXTRA HEAVY DOORS

dormakabaz