
TMP No. 08279262 | Page 1 of 2 Rev. 12/08 Always consult Dorma's web site for latest template at www.dorma-usa.com or call 1-800-523-8483. WELD BOTH REINFORCEMENT PLATES TO 8532 MOUNTING CHANNEL ON TOP AND SIDES EDGE OF REINFORCEMENT PLATES TO BE FLUSH REINFORCEMENT PLATE WITH HINGE SIDE OF 8532 MOUNTING CHANNEL TWO (2) REQUIRED (BY OTHERS) 3/16 SEE NOTE 6 (5)1-3/4 (44)1/8" X 45° CHAMFER 4-3/16 -MOUNTING CHANNEL WIDTH (106)BOTTOM EDGES OF REINFORCEMENT PLATES TO BE THIS END FLUSH WITH BOTTOM OF 8532 MOUNTING CHANNEL TOWARD HINGE JAMB MIN. (51)EDGE OF 8532 MOUNTING CHANNEL TO BE FLUSH WITH FACE OF HINGE JAMB 2-5/32 (55)4-1/2 (114)FRONT VIEW MINIMUM FRAME WIDTH 2-3/4 WELD REINFORCEMENT PLATES SECURELY TO INSIDE OF HEADER 1-11/32" DIA. CLEARANCE HOLE 13/16 NOTF: 9/16 8-1/32 9/16 1. DO NOT SCALE DRAWING. (14)(21)(204)(14)2. DIMENSIONS ARE IN INCHES/(MM). 3. MINIMUM HEADER SIZE 2" X 4-1/2". 4. CUT OUT FOR COVER PLATE **BOTTOM VIEW** 3-3/4" X 15-3/4". 3-23/32 (COVER PLATE ONLY) 3 - 3/81-3/4 5. CLEARANCE BETWEEN HEADER (94)(86) AND DOOR 1/8". (44)6. WIDTH OF REINFORCEMENT PLATE TO BE A SLIP FIT INTO INSIDE OF HEADER. **COVER PLATE 8575** 7. 90°HO MODELS NOMINAL HOLD OPEN 3/16" DRILL 7/16" DIA. TWO (2) 2-3/4 105°HO MODELS NOMINAL HOLD OPEN CSK 82° X 11/32" **CLEARANCE HOLES** AT 103°. (70)TWO (2) HOLES 15-23/32 8. AUXILIARY STOP REQUIRED COINCIDING WITH DEADSTOP ON RTS CLOSER. (399)

DOOR CLOSER MODEL: RTS SERIES PACKAGE 28, WOOD DOOR AND STEEL FRAME PREPARATION, DOOR HUNG ON 4-1/2" WIDE BUTT HINGES No. 8532 MOUNTING CHANNEL, No. 8812 TRACK ARM, No. 8575 COVER PLATE



DORMA Door Controls Reamstown, PA 17567



Always consult Dorma's web site for latest template at www.dorma-usa.com or call 1-800-523-8483.



Reamstown, PA 17567