

# Saffire LX-P & Saffire EVO LZ-P

Surface mount  
Drilling template

# LHR

**WARNING**




- To verify lock coverage and door operation meets expectations, dormakaba strongly recommends completing a full door mockup. This will ensure that all necessary products and parts for a successful installation are included.
- Always validate that you have selected the correct template for specific lock model being installed. The same lock model can be offered with different locking device options.
- Always validate after printing to confirm the dimensions listed on the drawing have printed on a 1:1 scale.
- If you have any questions, please contact your local sales representative or authorized reseller.

HOLE ID	DIM inch/[mm]	∇ inch/[mm]	COMMENTS
C	∅ 1-1/8 [28.6]	*	-
D	∅ 3/4 [19.05]	*	-
E	∅ 3/4 [19.05]	∇ 3/4 [19.05]	-
X	∅ 1/4 [6.35]	∇ 1/4 [6.35]	SEE NOTE #3

\*UNLESS OTHERWISE NOTED,  
DRILL HALF DOOR THICKNESS ON BOTH SIDES.

**NOTES:**

- THESE HOLES CORRESPOND TO HOLE PATTERN OF SURFACE MOUNT EXIT DEVICES. FOR COMPLETE HOLE PATTERN REFER TO SPECIFIC MODEL DRILLING TEMPLATE.
- DIMENSIONS ARE SYMMETRICAL ABOUT  $\phi$  UNLESS OTHERWISE NOTED.
- GROOVE TO BE DONE ONLY IN SOLID DOORS. TO PASS WIRES INSIDE THE DOOR FOR HOLLOW DOORS.
- SYMBOLS:
  - ∇ DEEP
  - $\phi$  CENTERLINE OF DOOR
  - ∅ DIAMETER
- ALL DIMENSIONS ARE IN INCHES [mm].



# RHR

