


INSTALLATION INSTRUCTIONS:

1. Determine unit type: (S) DEAD STOP ONLY or (H) HOLD OPEN.
2. Determine degree of hold-open or dead stop required and select the "A", "B" and "C" dimensions from the opposite side of this page.
3. Prepare door and frame according to the template found on this page.
4. Place end blocks into each end of track. Attach track and arm assembly to door, making sure spring faces toward hinges.
5. Attach soffit plate to frame.

* ADDITIONAL INSTRUCTIONS (HOLD-OPEN UNITS):

6. Adjust hold-open to on or off position. One direction on-opposite direction off.
7. Adjust the holding force by inserting a 5/64" hex key into the slide shoe bolt. Turn right to increase and left to decrease holding force.
8. Open door until slide shoe engages with hold-open.
9. To release the door, pull until the slide shoe disengages.



- NOTES:
1. DIMENSIONS ARE IN INCHES/(MM).
 2. LEFT HAND DOOR SHOWN.

STOP AND HOLDER SERIES: 701H - 703H, 701S - 703S
STANDARD DUTY SURFACE APPLIED STOP/HOLDER
PUSH SIDE MOUNT
CENTER HUNG, 3/4" OFFSET AND 4-1/2" x 4-1/2" HINGES

700S, 700H SERIES STANDARD DUTY SURFACE OVERHEAD STOP AND HOLDER

UNIT	DEGREE OF OPENING	4-1/2" HINGES OR 3/4" PIVOTS			CENTER HUNG			DIM "C"	DEGREE OF OPENING	UNIT
		DOOR RANGE	DIM "A"	DIM "B"	DOOR RANGE	DIM "A"	DIM "B"			
701 S	85° DEAD STOP ONLY	21 to 27	3-1/4	4-1/2	24 to 28	4-7/16	4-1/2	14-3/4	85° DEAD STOP ONLY	701 S
	90° DEAD STOP ONLY		2-7/8	4-1/2		4-1/16	4-1/2		90° DEAD STOP ONLY	
	95° DEAD STOP ONLY		2-1/2	4-1/2		3-3/4	4-1/2		95° DEAD STOP ONLY	
	100° DEAD STOP ONLY		2-1/4	4-1/2		3-7/16	4-1/2		100° DEAD STOP ONLY	
	105° DEAD STOP ONLY		2	4-1/2		3-1/8	4-1/2		105° DEAD STOP ONLY	
	110° DEAD STOP ONLY		1-5/8	4-1/2		2-7/8	4-1/2		110° DEAD STOP ONLY	
701 H	85° HOLD OPEN	21 to 27	2-1/2	4-1/2	24 to 28	3-3/4	4-1/2	14-3/4	85° HOLD OPEN	701 H
	90° HOLD OPEN		2-1/8	4-1/2		3-3/8	4-1/2		90° HOLD OPEN	
	95° HOLD OPEN		1-13/16	4-1/2		3-1/16	4-1/2		95° HOLD OPEN	
	100° HOLD OPEN		1-9/16	4-1/2		2-3/4	4-1/2		100° HOLD OPEN	
	105° HOLD OPEN		1-3/8	4		2-7/16	4-1/2		105° HOLD OPEN	
	110° HOLD OPEN		1-1/8	4		2-3/16	4-1/2		110° HOLD OPEN	
702 S	85° DEAD STOP ONLY	27-1/8 to 36	6	6-3/4	28-1/8 to 36	7-3/16	6	17-1/4	85° DEAD STOP ONLY	702 S
	90° DEAD STOP ONLY		5-3/8	6-3/4		6-3/4	6		90° DEAD STOP ONLY	
	95° DEAD STOP ONLY		4-15/16	6-3/4		6-1/4	6		95° DEAD STOP ONLY	
	100° DEAD STOP ONLY		4-15/16	5-1/2		5-7/8	6		100° DEAD STOP ONLY	
	105° DEAD STOP ONLY		4-5/8	5-1/2		5-5/16	6		105° DEAD STOP ONLY	
	110° DEAD STOP ONLY		4-1/4	5-1/2		5-1/16	6		110° DEAD STOP ONLY	
702 H	85° HOLD OPEN	27-1/8 to 36	5-7/16	5-1/2	28-1/8 to 36	6-1/8	7	17-1/4	85° HOLD OPEN	702 H
	90° HOLD OPEN		5	5-1/2		5-5/8	7		90° HOLD OPEN	
	95° HOLD OPEN		4-5/8	5-1/2		5-1/16	7		95° HOLD OPEN	
	100° HOLD OPEN		4-1/4	5-1/2		5-1/8	6		100° HOLD OPEN	
	105° HOLD OPEN		3-7/8	5-1/2		4-3/4	6		105° HOLD OPEN	
	110° HOLD OPEN		3-9/16	5-1/2		4-3/8	6		110° HOLD OPEN	
703 S	85° DEAD STOP ONLY	36-1/8 to 54	9-1/2	9-1/8	36-1/8 to 54	9-1/2	10	20-3/4	85° DEAD STOP ONLY	703 S
	90° DEAD STOP ONLY		8-3/4	9-1/8		8-11/16	10		90° DEAD STOP ONLY	
	95° DEAD STOP ONLY		8-1/8	9-1/8		7-15/16	10		95° DEAD STOP ONLY	
	100° DEAD STOP ONLY		8	8-1/8		7-15/16	9		100° DEAD STOP ONLY	
	105° DEAD STOP ONLY		7-5/16	8-1/8		7-5/16	9		105° DEAD STOP ONLY	
	110° DEAD STOP ONLY		7	8-1/8		6-13/16	9		110° DEAD STOP ONLY	
703 H	85° HOLD OPEN	36-1/8 to 54	9-13/16	9-1/8	36-1/8 to 54	9-5/16	10	20-3/4	85° HOLD OPEN	703 H
	90° HOLD OPEN		8-1/8	9-1/8		8-1/2	10		90° HOLD OPEN	
	95° HOLD OPEN		7-7/16	9-1/8		7-3/4	10		95° HOLD OPEN	
	100° HOLD OPEN		7-5/16	8-1/8		8	8-1/2		100° HOLD OPEN	
	105° HOLD OPEN		6-13/16	8-1/8		7-7/16	8-1/2		105° HOLD OPEN	
	110° HOLD OPEN		6-5/16	8-1/8		6-15/16	8-1/2		110° HOLD OPEN	

- a. All 4-1/2" WIDE HINGE and 3/4" OFFSET PIVOT dimensions are for 1-3/4" thick doors, CENTER HUNG are for 1-3/4" to 2-1/4" thick doors. For additional door thicknesses consult dormakaba's Technical Services department.
- b. DEAD STOP ONLY is the maximum degree to which the door will open when the shock spring is fully compressed.
- c. HOLD OPEN is the degree the door is held open. The shock absorber spring compresses while the door moves to the dead stop position which is several degrees greater (approximately 8-9 degrees).
- d. All values are in inches.