

TS9356 PKT 90/119

Surface Applied Closer

Pocket door track mount in 90°/119° pocket
(Track on wall)

Installation instructions

08280111 – 08-2019

| EN |














dormakaba 

Table of contents

| | | |
|----------|--|----------|
| 1 | Technical specifications | 3 |
| 1.1 | Overview | 3 |
| 1.2 | Size selection chart | 3 |
| 1.3 | Tools recommended | 3 |
| 1.4 | Surface closer system | 4 |
| 1.5 | Handling the door | 4 |
| 2 | Installation instructions | 5 |
| 2.1 | Installing the back plate | 5 |
| 2.2 | Installing the surface closer | 5 |
| 2.3 | Installing track assembly | 5 |
| 2.4 | Installing main arm | 6 |
| 2.5 | Secure main arm | 6 |
| 3 | Adjustments | 7 |
| 3.1 | Adjust closing speeds: sweep, latch, backcheck, delayed action | 7 |
| 3.2 | Adjust spring force | 8 |
| 4 | Install covers | 8 |

1 Technical specifications

1.1 Overview

-  Caution: sex nuts are required for attachment of components to unreinforced doors and to wood or plastic faced composite type fire doors, unless an alternative method is identified in the individual door manufacturer's listings.
-  Maximum degree of opening is 119°.
-  Minimum door width is 32".
-  Adjust closer spring tension for proper closing and latching of door.
-  Adequate reinforcement by others required to install track in pocket.
-  Pocket depth is measured from the pull side face of the door at maximum opening.
-  Requires DORMA EM504 electromagnetic door holder
-  Use closer body style "B" for this installation.
-  Arrows on closer mounting plate point upward.
-  Follow included template to properly prepare door and frame for all accessories of the closer installation.
-  Know the swing of the door which is being installed prior to installation.
-  Make sure door efficiently operates prior to installing closer.
-  Verify closer spring size prior to installation.

1.2 Size selection chart

Table 1

| Closer | Door width range | Maximum weight |
|-------------------|------------------|----------------|
| TS9356 PKT 90/119 | 2'-8" to 4'" | 150lbs |


1.3 Tools recommended

Table 2

| | |
|---------------------------|-------------------------|
| Drill bits: | #2 Phillips screwdriver |
| Metal: No. 21 & 10-32 tap | M2.5 hex key |
| Wood: 1/8" | M5 hex key |

1.4 Surface closer system

Fig.1




The surface closer is comprised of the following components.

- | | |
|-----------------------|-----------------------------------|
| 1. Closer body | 6. Closing/sweep speed adjustment |
| 2. Main arm | 7. Latch speed adjustment |
| 3. Track assembly | 8. Backcheck adjustment |
| 4. Pinion | 9. Delayed action adjustment |
| 5. Cover and end caps | 10. Backplate |

1.5 Handing the door


Fig.2



2 Installation instructions

2.1 Installing the back plate

Fig.3




Reference template 08280112

- 2.1.1 Attach the back plate to the installing surface using the four screws [10-32 machine screws or #10 wood screws] provided with the surface closer.

2.2 Installing the surface closer


Fig.4



- 2.2.1 Secure the closer body (2) to the plate using the four M5x47mm flathead Phillips screws (3) provided with the plate itself.

2.3 Installing track assembly

Fig.5




- 2.3.1 Position the components inside the track channel (1).
2.3.2 Attach the track channel to the wall through the end blocks with two flat head Phillips screws (2).

- A. End block
B. Track channel
C. Slide shoe

2.4 Installing main arm

Fig.6




2.4.1 Align the arm (1) with the slide shoe of the track channel.

2.4.2 Secure with one M8x15mm shoulder bolt (2) using an M5 hex key.

2.5 Secure main arm

Fig.7



- 2.5.1 With the door closed and using an adjustable wrench (looking up at the bottom of the closer):
- **Left hand door** - turn the bottom pinion clockwise approximately 5°.
 - **Right hand door** - turn the bottom pinion counter-clockwise approximately 5°.

2.5.2 Attach the main arm (1) to the top pinion with an M6x20 socket head cap screw (2) using an M5 hex key.



Be sure that the door is fully closed during application.


3 Adjustments

- ⚠ Set closer spring size prior to making any closing speed adjustments.
- ⚠ Do not back valves out beyond closer casting.

- ⚠ Maximum opening angle is 119°.
- ⚠ Door should close in 3 to 6 seconds from 90°.
- ⚠ Do not close valves completely.

3.1 Adjust closing speeds: sweep, latch, backcheck, delayed action

Fig.8



3.1.1 Adjust the **closing sweep speed** (1) for the area from 70° - 0°

- Increase sweep speed: Turn valve counter-clockwise
- Decrease sweep speed: Turn valve clockwise.

3.1.2 Adjust the **closing latch speed** (2) for the area from 7° - 0°.

- Increase latch speed: Turn valve counter-clockwise
- Decrease latch speed: Turn valve clockwise.

3.1.3 Adjust the **opening backcheck** (3).


- Increase resistance: Turn valve clockwise
- Decrease resistance: Turn valve counter-clockwise.

3.1.4 Adjust the **closing delayed action** (4) for the area from 119° - 70°.

- Increase delayed action: Turn valve clockwise
- Decrease delayed action: Turn valve counter-clockwise

3.2 Adjust spring force

Fig.9




| | Door width | Full turns of spring adjust | Closer size |
|--------|------------|-----------------------------|-------------|
| TS9356 | 4' | 0 | 5 |
| | 4'-6" | +5 | 6 |

TS9356

NOTE: Supplied with a size 6 spring setting.
Increase force: turn clockwise 6 times (max)

4 Install covers

Fig.10



4.1.1 Snap both end covers (1) into place.

4.1.2 Remove the un-needed tab (2), and snap the closer body cover (3) into place.

4.1.3 Secure with a 4-40 Phillips pan head screw (4) .

