

**Template A**  
(with passage set)  
**right-hand**

**CAUTION**  
Apply template and drill from outside, but compensate for door bevel if any.

Door bevel

**Mark center of door thickness.**

1-3/8" [35mm]  
1-1/2" [38mm]  
1-3/4" [44mm]  
2" [51mm]  
2-1/4" [57mm]


2-1/4" [57mm]  
2" [51mm]  
1-3/4" [44mm]  
1-1/2" [38mm]  
1-3/8" [35mm]

**Cross bore**  
1" (25mm) diam. latch hole

**For 2-3/4" (70mm): This flap folds over the edge of the door.**  
Ensure the fold is exactly on the line.

**For 2-3/8" (60mm): This flap folds over the edge of the door.**  
Ensure the fold is exactly on the line.

Ensure the fold is exactly on the line.



**For 2-3/4" (70mm): This flap folds over the edge of the door.**  
Ensure the fold is exactly on the line.

**For 2-3/8" (60mm): This flap folds over the edge of the door.**  
Ensure the fold is exactly on the line.

**Template A**  
(with passage set)  
**left-hand**

**NOTE:** Lock will accommodate doors 1-3/8" (35mm) to 2-1/4" (57mm) thick. Suitable reinforcement shall be provided by the hollow metal door manufacturer to prevent collapsing of door. When door silencers are to be installed, proper allowances must be made for strike location.

**Mark center of door thickness.**

1-3/8" [35mm]  
1-1/2" [38mm]  
1-3/4" [44mm]  
2" [51mm]  
2-1/4" [57mm]

2-1/4" [57mm]  
2" [51mm]  
1-3/4" [44mm]  
1-1/2" [38mm]  
1-3/8" [35mm]

**Cross bore**  
1" (25mm) diam. latch hole